

SPEEDSTRIP

THE ULTIMATE IN PLATON WATERPROOFING INSTALLATION

Fast
Strong
Secure



- NO CAULKING REQUIRED !!!
 - Chalk a line at finished grade. *(Please read general instructions included in every roll)*
 - Unroll Platon, dimples toward the wall, smooth tab following the chalk line.
 - Tack the Platon in place with a fastener* in the third row of dimples every 10'.
 - Overlap vertical seams by 20" and continue until the foundation is wrapped.
 - Mesh the Speedstrip into the top row and a half of Platon dimples using the half-moon marks as a guide. *(Speedstrips do not butt tightly - there will be a small gap between each Speedstrip)*
 - Secure with fasteners* through the small holes in the "fastening area" marked on the Speedstrip. *(on ICF's - stay in the fastening area and screw into the ICF webs - 6" or 8" apart)*
 - Windows - cut Platon flush with the sides and 3" lower than the window opening. Install a Speedstrip across the bottom of the window, install the window well over the Platon.
 - Gradual change in grade - Measure length of sloping chalk line, add 20" for overlap, cut that length of Platon & install with the smooth tab following the chalk line. Cut off surplus membrane at the bottom.
 - Steep change in grade - Cut membrane to proposed finished grade, exposing the air gap. Nail Speedstrips to secure the Platon and close off the air gap. Nail in both the fastening area and offset area in a "W" pattern.
- * Fasteners - Use 1 1/4" concrete nails - 1 5/8" screws on ICF or wood foundations.



Call Toll Free
1-800-265-7622

